Crystal and Cavity Characterization

Introduction to digital Low-Level Radio Frequency Controls in Accelerators

Lab 1 and Lab 2

Shreeharshini Dharanesh Murthy, Dmitry Teytelman, Dan Wang, Qiang Du

Contents


Introduction
1.1 Hardware setup
1.2 Software setup
1.3 Reference
Exercise
2.1 Crystals:
2.2 Cavities:
Reference Capture S21 response using nanoVNA

1 Introduction

In this lab we are going to measure the frequency response using the provided nanoVNA network analyzer.

NanoVNA is able to be controlled via USB serial interface from PC. There are sample scripts in this directory.

1.1 Hardware setup



Toggle the power switch of nanoVNA to ON.

1.2 Software setup

Pre-requirement:

- \$ cd python
- \$ pip3 install -r requirements.txt

Usage of drive nanovna.py:

- Plot reflection LOGMAG.
 - \$./nanovna.py -p -P 0 -S 39.7e6 -E 40.3e6
- Plot transmission LOGMAG.
 - \$./nanovna.py -p -P 1 -S 39.7e6 -E 40.3e6

1.3 Reference

- NanoVNA repository
- NanoVNA manual

2 Exercise

2.1 Crystals:

- 1. Assuming the Nano-VNA is calibrated (2-port calibration) with center of 20 MHz and span of 1 kHz, captures live data from Nano-VNA.
- 2. Calculate the 3dB bandwidth, Quality factors $(Q_0 \text{ and } Q_L)$, and coupling factor.

2.2 Cavities:

- 1. For a given cavity, find it's resonance frequency.
- 2. Assuming the Nano-VNA is calibrated (2-port calibration) with center of resonance frequency and required span, capture live data from Nano-VNA.
- 3. Calculate the 3dB bandwidth, Quality factors $(Q_0 \text{ and } Q_L)$, and coupling factor.

3 Reference Capture S21 response using nanoVNA

Note: the following example uses a 40.0MHz crystal instead the provided 20.00MHz crystal.

Please analysis the data using mathematical concepts taught in the class, and you may compare with results with the skrf functions like shown below.

```
[1]: %matplotlib inline
from nanovna import NanoVNA
from matplotlib import pyplot as plt
import skrf as rf
rf.stylely()
```


```
[2]: # define freq range
start_f, stop_f = 39.9e6, 40.1e6

# create instance and connect to the device
nv = NanoVNA()
nv.set_sweep(start_f, stop_f)
nv.fetch_frequencies()
```

```
[3]: s11 = nv.data(0)
s21 = nv.data(1)
```


```
[4]: resonator = nv.skrf_network(s21)
```

[5]: resonator.plot_s_db(label='S21')



```
[6]: Q = rf.Qfactor(resonator, res_type='transmission')
res = Q.fit()
```

- [8]: Q
- [8]: Q-factor of Network None. (fitted: $f_L=40.000MHz$, $Q_L=30424.697$)
- [9]: new_freq = rf.Frequency(start_f / 1e6, stop_f / 1e6, npoints=5001, upunit='MHz')
 fitted_network = Q.fitted_network(res, frequency=new_freq)
- [10]: resonator.plot_s_mag(label='Measured', lw=1) fitted_network.plot_s_mag(label='Fitted Model', lw=1, ls='--')



```
[11]: print(f'Bandwidth: {Q.BW:.3f} Hz')
```

Bandwidth: 1314.734 Hz

